



Screen Anti-Bow Clip Installation Instructions

NOTE: Anti-bow clips are to be installed over the screen insert (one clip per side) at the center of the vertical screen frame members.

From the inside of door:

1. Remove vinyl retainer strips.
2. Position anti-bow clip (Figure 2)
3. Center clip in the middle of screen frame. Mark, then drill a 3/32" pilot hole.
4. Fasten clip to door with #6 x 5/8" screw provided.
5. Install the second clip on the opposite side, repeating the first four steps.
6. Notch the vinyl retainer (Figure 3) so that the anti-bow clip screw will not interfere with retainer installation.
7. Re-install vinyl retainer strips over the anti-bow screen clips (Figure 4).

