



Cleaning Low-E Glass

Clean the glass with plain water, using a clean soft sponge or lint-free cloth to remove as much surface grime from the glass as possible. If needed, wash the surface of the glass again with a solution of 80% water and 20% vinegar with a clean soft lint-free cloth. Dry with a new soft cloth.

Cleaning may cause streaks when dried if the glass is exceptionally dirty. In this case repeat the above steps.

NOTE:

- Care must be exercised when using rubber squeegees on the coated surface, as they can leave streaks that are hard to remove if they are used incorrectly or are in poor condition.
- Never use ANY type of scraper or abrasive cleaner on the coated surface. Particles from these materials can be deposited on the coated surface and are very difficult to remove.
- For unusually hard to remove spots such as crayon or grease, isopropyl alcohol, GooGone® or GoofOff® may be used. After spot cleaning, the full glass surface should be cleaned as discussed above.